

FITTING INSTRUCTIONS

IMPORTANT: Before fitting ensure your hard hat is clean and free of oil, grease & dust.



Step 1

Complete the waterproof ID card with your emergency medical, allergy & contact details using a fine-tip permanent marker.



Step 2

Insert completed ID Card into the sleeve.



Step 3

Fit ID sleeve to LEFT side of hard hat by peeling off backing.



Step 4

Fold over seal & press down firmly to secure.



Step 5

Wear safely.



For more information

www.workersafetyid.com

To see our full range of ID solutions visit our website www.vitalid.ca